

PEDAK DISPLAY

Manual P5 / P7



Content:

1. Basic Requirements and Safety	3
2. Technical Specifications and Description	4
3. Mounting Instructions	7
4. Wiring Diagram, Display explanation	8
5. Settings	14
5.1. Main Settings	14
5.2. Sensor Input	17
- Modbus TCP Server	17
- Modbus RS485 Client	18
- Analog Input	19
- Digital Input	20
- nSens Input	21
- Puzzle IO Input	22
5.3 Field	23
5.4 Save	28
5.5 Back	28
6 Out of use Function	29
7 Day – Night Function	29
8 Download the Logfile via WiFi	30
9 Modbus	32
- Modbus TCP/IP (Switch - Slave)	32
- Modbus TCP/IP (Server - Master)	33
- Modbus RS-485 (Client - Master)	34
- Modbus Registers – for “Master” modus	34
- Modbus registers – for “Slave” modus	35
- Modbus Connection	38
10 Default Factory Settings	39
11 Menu Layout	40
12 Screen Layout	41
13 Trouble Shootings	42
14 Expansion Modules	43
15 Ordering Codes	43

Manual revision 31.07.2026

PEDAK-P5/P7

No part of this manual may be reproduced, stored in a retrieval system, or transmitted in any form or by any means for commercial purposes without prior written permission from **PEDAK meettechniek B.V.**®.

Specifications and contents of this manual are subject to change without notice.

Copyright © PEDAK meettechniek BV® - All rights reserved.

1. BASIC REQUIREMENTS AND SAFETY:



The manufacturer is not responsible for any damages caused by inappropriate installation, not maintaining the proper Technical condition and using the unit against its destination.

Installation should be conducted by qualified personal. During installation all available safety requirements should be considered. The fitter is responsible for executing the installation according to this manual, local safety and EMC regulations.

The unit must be properly set-up, according to the application. Incorrect configuration can cause defective operation, which can lead to unit damage or an accident.

If in the case of a defect of unit operation there is a risk of a serious threat to the safety of people or property additional, independent systems and Solutions to prevent such a threat must be used.

The unit uses dangerous voltage that can cause a lethal accident. The unit must be switched off and disconnected from the power supply prior to starting installation of troubleshooting (in case of malfunction).

Neighboring and mating equipment must meet the requirements of appropriate standards and regulations. Concerning safety and be equipped with adequate anti-overvoltage and anti-interference filters.

Do not attempt to disassemble, repair or modify the unit yourself. The unit has no user serviceable parts. Units, in which a defect was stated must be disconnected and submitted for repair at an authorized service center.



In order to minimize fire or electric shock hazard, the unit must be protected against atmospheric precipitation and excessive humidity.

Do not use the unit in areas threatened with excessive shocks, vibrations, dust, humidity, corrosive gasses and oils.

Do not use the unit in explosion hazard areas.

Do not use the unit in areas with significant temperature variations, exposed to condensation or icing

Do not use the unit in areas exposed to direct sunlight.

Make sure that the ambient temperature (e.g. inside the control box) does not exceed the recommended values. In such cases forced cooling of the unit must be considered (e.g. a ventilator)

The unit is designed for operation in a non-industrial environment and must be used in this way.

2. TECHNICAL SPECIFICATIONS:

P5:

Power supply	DC 24V+/- 20%
Power consumption	170mA
Display	5" TFT display with capacitive touch screen
Protection class	Front IP65 / Wiring IP00
Dimensions	171 x 121 x 35 mm
Mounting hole Display	145 x 95 mm
Mounting hole Wall box	156 x 106 mm
Casing type	Panel, snap in
Ambient temperature	-10°C tot +50°C
Humidity	5% till 90% non-condensing
Wiring	Via connectors on the bottom
Interfaces	RS485, CAN-bus, RS232, USB (manufacturer purpose only)
Ethernet	Standard 10/100 Mbit/s (no POE)
SD input	Micro SD, standard PC compatible
GND	Shared with power supply and inputs
Supplied	Display (5"), Wall Box, Cable gland, grommets



P7:

Power supply	DC 24V+/- 20%
Power consumption	200mA
Display	7" TFT display with capacitive touch screen
Protection class	Front IP65 / Wiring IP00
Dimensions	216 x 145 x 35 mm
Mounting hole Display	190 x 120 mm
Mounting hole Wall box	201 x 131 mm
Casing type	Panel, snap in
Ambient temperature	-10°C tot +50°C
Humidity	5% till 90% non-condensing
Wiring	Via connectors on the bottom
Interfaces	RS485, CAN-bus, RS232, USB (manufacturer purpose only)
Ethernet	Standard 10/100 Mbit/s [RJ45] (no POE)
SD input	Micro SD, standard PC compatible
GND	Shared with power supply and inputs
Supplied	Display (7"), Wall Box, Cable gland, grommets



PRIObox:

Power supply Priobox	230VAC (pre assembled with 2,5 m cable with EU connector)
Dimensions Priobox	255 x 180 x 85 mm (excl. cable gland)
Power Supply Unit	Input 230VAC, output 24VDC / 1,5A (internally wired)
Sensor Supply	24VDC (max. 500mA) via terminal strips
Prio-print	DC 24V+/- 20% (internally wired)
Power consumption	170mA
Dimensions Prioprint	170 x 85 x 55 mm
Casing type	DIN Mounting rail
Ambient temperature	-10°C to +50°C
Humidity	5% till 90% non-condensing
Wiring	Via connectors on the top
Interfaces	RS485, Wi-Fi, Bluetooth
N-Bus	4 x N-bus (Novasina nSens)
Analog Inputs	4 x Analog Inputs* galvanically isolated (0-5V; 0-10V; 0-20mA; 4-20mA, selectable via jumper setting)
Digital Inputs	2 x 24VDC PNP Digital Inputs *
Outputs	2 x Relays (NO,NC,COM) - 230VAC – 8A / 24VDC – 8A I/O expansion connector *
Ethernet	Standard 10/100 Mbit/s [RJ45] (no POE)
GND	Shared with power supply, digital inputs and interfaces
Analog GND	Each analog input is galvanically isolated and has its own isolated ground (Prio-print only)



*** can be extended up to 8 analogue/digital inputs and/or 4 relays (under development) by using Puzzle-modules**



Products mentioned in this manual should not be placed in municipal waste. Please check local regulations for disposal of electronic products.

Description:

The display can show up to 8 inputs simultaneously (user selectable).

Each input can independently generate visual and acoustic alarm (user selectable).

In case of an alarm the background color will change from white or green (no alarm) to yellow (pre alarm) or red (alarm) and an acoustic alarm buzzer will sound (if selected).

The buzzer sound can be muted, while the background color remains unchanged.

The display can be used in combination with the **PRIO-box** to connect 4x Analog and/or 2x Digital inputs as well as 4x Novasina (nSens) sensors *[without Novasina transmitters]*.

The PRIO-box also provides 2 relays.

The digital inputs can be used as *door counter* via a 24VDC pulse (if necessary supplied by the unit {max. 0.5A}), alarms can also be configured.

The counter can count upwards and can manually be reset to "Zero".

The digital input also can be used to display (user defined) text into a specified field in the display. As long as the 24VDC puls is high the text will be displayed.

All settings can be made via the touch screen, However jumpers need to be set on the back to select the proper analog input (mA or V).

The unit can configured to display a status message, by touching the lock symbol and the message "Out of Service" will be displayed.

NOTE: In "Out of Service" status, all alarm will be suppressed !!

By selecting the Toggle function the display can be used to manually activate or deactivate a relay.


It is also possible to connect Modbus signals directly to the display without using the PRIO-box:

- When connected to devices the display will function as a **Modbus-Master**.
- When connected to a TCP/IP network or BMS the display will function as a **Modbus-Slave**.

Measured data can automatically be saved on the SD-card and can be downloaded via Wifi (in combination with the PRIObox only).


By touching a specific input field the graphics of the measured data of this field will be displayed.

The display can be used in a horizontal (landscape) or vertical (portrait) position (user selectable).



3. MOUNTING INSTRUCTIONS:

Mount the required number of cable glands/grommets in the desired positions in the mounting frame by removing the round metal parts first.



Cut out the required opening (A) in the wall according specified dimensions
(Wall box P5: 156 x 106 mm / Wall box P7: 201 x 131 mm).




Display can be configured to a Horizontal (landscape) or Vertical (portrait) orientation !



Ensure the mounting frame is mounted level !

Slide the mounting frame in the wall opening (A) and bend the clips (B) to the secure it in place.

Connect the wiring and insert the display in the mounting frame by pressing the spring clips (C) on both sides inwards, the spring clips (C) will prevent the display from falling out.



4. WIRE DIAGRAM:

PRIObox


Open the lid from the PRIObox by unscrewing the 4 screws at each corner.

Mount the PRIObox at the desired location via the 4 mounting holes (A).


Insert the sensor cables through the cable glands and connect the sensor(s), relay output, RJ45 cable and power supply for the display (P5/P7) to the designated (screw) terminals on the Prio print.

Power supply for the sensors can be taken from the 24VDC terminal trips (max. 500mA) if needed.


Close the Lid and tighten the 4 screws at each corner.




P5/P7 Display:




PRIO-print:




Connection Display with PRIO-box (via UTP cable)



Connection Display Modbus TCP/IP (Modbus-Server or Modbus-Switch)




Connection Display with Modbus RS-485 (Modbus-Client)



⚠ NOTE: The RS-485 connection can be used in combination with the PRIO-box.
But the RS-485 Baud rate must **not** be set higher than **9600** !

Display explanation:




- 1 PEDAK logo [press to enter the Menu]
- 2 Time [Time can be set in the Main Menu]
- 3 Lock or Unlock the Display [“out of use” modus – see chapter 6]
- 4 Day or Night modus [brightness can be set in the Main Menu – see chapter 7]
- 5 Text Left [can be set in the Field Menu]
- 6 Text Right [can be set in Field Menu]
- 7 Measured Value
- 8 Unit [can be set in the Field Menu]
- 9 Buzzer Mute symbol [buzzer can be muted by touching the buzzer symbol]
- 10 Relay closed symbol [Relay active - relay can be set in the Field Menu]
- 11 Buzzer symbol [buzzer can be set in the Field Menu - only visible in Pre-alarm or Alarm status]
- 12 Relay open symbol [Relay inactive - relay can be set in the Field Menu]
- 13 Yellow background colour [Pre Alarm Status – can be set in the Field Menu]
- 14 Red background colour [Alarm Status – can be set in the Field Menu]
- 15 Green background colour [No Alarm Status – can be set in the Field Menu]
- 16 White background colour [No Alarm Status – can be set in the Field Menu]



Setting 5 till 16 must be done for each field separately




Font size for Text Left and Text Right can be set in the Field Menu (for each Field)
Font size for Value and Unit can be set in the Field Menu (for each Field)



- 1 Field Text Left
- 2 Measurement Unit
- 3 Back to measuring modus
- 4 1 hour graphic scaling
- 5 8 hour graphic scaling
- 6 24 hour graphic scaling
- 7 High Alarm line
- 8 High Pre-alarm line
- 9 Measurement Graphics
- 10 Low Pre-alarm line
- 11 Low Alarm line
- 12 Range scaling
- 13 Time scaling

5.1 MAIN SETTINGS:

Click on the **PEDAK** logo to enter the settings



The diagram illustrates the process of entering the settings. It starts with a hand clicking the PEDAK logo, which leads to a menu with five options: Main settings, Sensor input, Field, Save, and Back. A hand is shown clicking 'Main settings', which leads to the 'Main settings' screen. The screen has a 'Back' button at the top right. The settings are organized into sections: Language, Brightness, Screen, Pin code, Wifi Network, Logfile Information, Buzzer, Network, IP settings, Time and Date, System info, Factory reset, Restart, and Switch version. Each section contains specific configuration options with input fields, dropdown menus, and toggle switches.

Main settings

Back

Language

Language English ▾

Brightness

Brightness day 100

Brightness night 10

Brightness delay (min) 0

Screen

Screen orientation Horizontal ▾

Number of active panels 4 ▾

Pin code

Code

Pin code enabled ☐

Wifi Network

Wifi name Pedak

Password Pedak1234

Enabled ☐

Logfile Information

Buzzer

Frequency Normal ▾

Network

Current IP 192.168.0.200

IP settings

Time and Date

Time 10:22:38

Date 10-07-2025

System info

Factory reset

Restart

Switch version



In the “Main settings” overall configurations can be made, such as screen layout, screen orientation, language, PIN code, etc.

Language: Select the display language. Select Dutch or English *[default]*

Brightness: Set the Day and/or Night (energy save) brightness of the display.

Default Day = 100%,

Default Night = 10%

Automatic switch from Day to Night modus by setting a delay time (in minutes)

Setting no delay time (zero) the automatic switch modus is OFF

Screen: Select the display layout. Horizontal (landscape) or Vertical (portrait)

Select how many active Fields you prefer. 1 up to max. 8 visible fields.

See [Chapter 12](#) for “Screen Layout”

Pin code: To protect the display for unauthorized use a PIN code can be set.

For the PIN code to be active you need to enable the Pin code 



If you forget the PIN code the display has to be returned to **PEDAK meettechniek** to be reset !

WiFi network: The display saves the measured values on the SD-card, by using the WiFi connection you can download the saved data on your smartphone for analyses *
[See Chapter 8: “Download the Logfile via Wi-Fi” for instructions].

WiFi network name and **WiFi Password** is shown *[default: Pedak, Pedak1234]*

Enable  or **Disable**  the WiFi network modus *[to readout stored data]*

Buzzer: Set the buzzer frequency to Normal or Low for different buzzer tones.

Network: If the display is connected via TCP/IP to your network the visible IP address can be used for Modbus communications.

Via **IP Settings** several network settings can be made or changed.

[See chapter 9: “Modbus” for instructions and Modbus registers]

Time and Date: Set the correct Time and Date

Time is showed in the display at all times, date is used for graphics

System info: Here the serial number, firmware version and the company info is shown **

Factory Reset: Select to set the display back to default factory settings *[see chapter 10].*



All the user programmed settings are erased !

Restart: Select to Restart the display without disconnecting the power supply.



All Graphics are reset ! *[Logfiles will remain]*

Switch version: Select to switch to Modbus only (slave) modus (TCP/IP) *** *[see chapter 9]*



Every setting must be done via Modbus !



Set the correct IP-address first ! *[via IP Settings – Default: 192.168.0.200]*

* (Logfile information)




** (System information)



*** (Switch Version)



5.2 SENSOR INPUT:



This input can be used to send the measured values to the display via TCP/IP connection.

NOTE: Measured values only, the rest of the settings must be done via the "Field" menu!

NOTE: You also need to set the IP-address via "Main Settings – IP Settings"

Register offset: Start address for the Modbus register [see sensor manual]


Channel 1 – Name: Enter your channel name [default: Modbus Srv 1]

Divisor: Sometimes it is needed to divide the input register to get the correct reading, enter the divisor value for correct readings.

Example: input value is 500 → reading should be 50 → divisor = 10

Swap bytes: Sometimes it is needed to swap bytes, this can be done by using the switch 

These settings must be done for each Channel separately.



Modbus RS485 Client

Serial settings

Baud rate: 115200

Data bits: 8

Parity: None

Stop bits: 1

Channel 1

Name: Modbus CI 1

Register number: 1

Divisor: 1.00

Swap bytes: ☐

Unit address: 1

Register type: Holding



Channel 8

Name: Modbus CI 8

Register number: 8

Divisor: 1.00

Swap bytes: ☐

Unit address: 1

Register type: Holding



This input can be used to send the measured values to the display via RS-485 connection.

NOTE: Measured values only, all other settings must be done via the “Field” menu!

NOTE: Make sure all settings of the sensor and display channel match!

Serial Settings: Enter the serial settings matching the sensor settings [default: 115200, 8N1]

Channel 1 – Name: Enter your channel name [default: Modbus CI 1]

Register number: Enter the register number you want to be displayed [see sensor manual]


Divisor: Sometimes it is needed to divide the input register to get the correct reading, enter the divisor value for correct readings.

Swap bytes: Sometimes it is needed to swap bytes, this can be done by using the switch ☒

Unit address: Enter the Unit address of the sensor you want to be displayed

Register type: Choose the needed register type (Holding or Integer) [see sensor manual]

These settings must be done for each Channel separately.



Analog input

Channel 1

Name: Analog 1

Input: 4..20mA

Input Min.: 826

Input Max.: 4094

Range Min.: 0.00

Range Max.: 100.00

Smoothing: 98.06

Back



Channel 4

Name: Analog 4

Input: 4..20mA

Input Min.: 826

Input Max.: 4094

Range Min.: 0.00

Range Max.: 100.00

Smoothing: 98.06



This input can be used to display Analog (mA/VDC) signals or Analog sensors via the PRIO-box.

NOTE: Measured values only, all other settings must be done via the "Field" menu!

NOTE: Make sure all Sensor settings and Display channel settings match!

Channel 1 – Name: Enter your channel name [default: Analog 1]

Input: Select the Analog signal (0/4-20mA, 0-5/10VDC)¹ [it must match the sensor]

Input Min: low calculation value (fixed value)

Input Max: High calculation value (fixed value)

Range Min: Enter the low measuring value that needs to be displayed [it must match the sensor]

Range Max: Enter the High measuring value that needs to be displayed [it must match the sensor]

Smoothing: Enter the Smoothing² value [value between 0-100%] [default: 98,06]

These settings must be done for each Channel separately.

¹ Also put the Jumper(s) in the correct position!

² This function converts the selected "smoothing" setting into a value that the EMA (Exponential Moving Average) filter uses to smooth measurements. The higher the smoothing, the smoother the signal appears, but the slower it reacts to rapid changes.



This input can be used as a counter of to show text on the Display via the PRIO-box / Slave I/O.

NOTE: Digital input only, the rest of the settings must be done via the “Field” menu!

NOTE: PRIO-box has 2 digital inputs, this can be extended up to 16 digital inputs (via Slave I/O)!

Input 1 - Name: Enter your channel name [*default: Digital 1*]

Channel: Select the digital channel to be used

Input type: Select if you want the digital input to behave as a Counter or State function.


Counter function¹: adds the value with 1 at each pulse (24VDC)

State function²: shows the added text as long as the pulse is high (24VDC)

These settings must be done for each Channel separately.

¹ Counter can be **RESET** by touching the counter screen for >2 sec. and confirm YES/NO.

² State settings via the FIELD menu at “Channel can be disabled”, enable the function , choose the digital input you want to use and enter the “Disable Text” you want to appear when the specific Digital input is activated



nSens sensor input

Back

Probe 1 Value 1

Name

Probe 1 Value 2

Name

Probe 2 Value 1

Name

Probe 2 Value 2

Name

Probe 3 Value 1

Name

Probe 3 Value 2

Name

Probe 4 Value 1

Name

Probe 4 Value 2

Name



This input can be used to display Novasina nSens/nLink+ sensors via the PRIO-box.

NOTE: Measured values only, the rest of the settings must be done in via the “Field” menu!

NOTE: Make sure all Sensor settings and Display channel settings match!

NOTE: max. 4x nSens can be connected to the PRIO-box

NOTE: 1 nSens can have more the 1 measuring value output !

for example: 1 sensor can have Humidity and Temperature output, so if you need them to be displayed both, you must enter “Probe 1 value 1” in “Field 1” and “Probe 1 Value 2” in “Field 2” (or whichever field you prefer)


Probe 1 Value 1 - Name: Enter your Sensor name [default: *nSens 1 Value 1*]

These settings must be done for each Channel separately.



To connect the nSens sensor cable please use the colour code that is mentioned on the circuit board.





Back

Analog input

Channel 1

Name

Input Min.

Input Max.

Range Min.

Range Max.

Channel 8

Name

Input Min.

Input Max.

Range Min.

Range Max.



This input can be used to display extra Analog (mA/VDC) or digital signals via the PRIO-box with expanded Puzzle Master I/O [see chapter 11].

NOTE: Measured values only, the rest of the settings must be done via the “Field” menu!

NOTE: Make sure all Sensor settings and Display channel settings match!

Channel 1 – Name: Enter your channel name [default: *P Analog 1*]

Input Min: low calculation value (0.00 for 0V or 0mA input / 819 for 4mA input, or custom)

Input Max: High calculation value (4096 for 5V/10V/20mA, or custom)

Range Min: Enter the low measuring value that needs to be displayed, it must match the sensor

Range Max: Enter the High measuring value that needs to be displayed, it must match the sensor

These settings must be done for each Channel separately.

Example: Analog Sensor → measuring range 0...50°C with 4...20mA output

Input Min. → 819 (matches 4 mA)

Input Max. → 4096 (matches 20 mA)

Range Min. → 0 (matches 0°C)

Range Max. → 50 (matches 50°C)



Puzzle Master I/O Module can also be used only with the Pedak-P5/P7 display or in combination with the PRIObox and have **NO** galvanic insulation!

5.3 FIELD:

Main Settings

Sensor Input

Field

Save

Back

Field 1

Field 2

Field 3

Field 4

Field 5

Field 6

Field 7

Field 8

Field 1

Back

Sensor input Analog 1

Text left Temperature

Text right Room 1

Unit °C

Text font size 30

Value font size 48

Decimals 1

Background green

Logging to file enabled

Channel can be disabled

Disable enable

Disable channel

Disable tekst

Toggle panel

Is toggle panel

Relais connected to toggle 0

Graph

Manual scaling enabled

Graph minimum 0.0

Graph maximum 100.0

Alarm

Enabled

Alarm delay (sec) 0

Low Settings

High Settings



In the “Field” menu settings can be made for each individual Field according the measured values, Alarms, Text, Background colour, etc.

Sensor input: Select the input you want to show in the specified field *[default: Analog 1]*

Text left: Enter the Text to be shown in the left upper side of the specified field

⚠ “Text Right” and “Text left” may overlap if too long !

Text right: Enter the Text to be shown in the right upper side of the specified field

⚠ “Text Right” and “Text left” may overlap if too long !

Unit: Enter Unit to be shown behind the measured value *[it must match the sensor]*

Text font size: Select the font size for the text up-right and up-left *[default: 30]*

Value font size: Select the font size for the measured value and unit *[default: 48]*

Decimals: Enter the number of decimals you want to show *[e.g.: 1 = 0.0 / 2 = 0.00]*

Background green: Select if you want the background to be white or green at no Alarm status

Logging to file enabled – disable enable: Select if the measured data must be saved

Disable channel: Select the channel you want to be disabled¹ *[it must be an active channel]*

Disable text: Enter the text you want to show if the specified channel is disabled

Toggle panel: Select if the field should toggle² and specify the relay to be used

Relay connected to toggle: Select the relay you want to be active during toggle *[default 1 or 2]*

Graph – Manual scaling enabled: Select between auto scaling or manual scaling

Graph minimum: Enter the value of graphical minimum *[at manual scaling only]*


Graph maximum: Enter the value of graphical maximum *[at manual scaling only]*

Alarm - Enabled: Select if the alarm should be enabled or disabled

Alarm delay (sec.): Enter the second(s) the alarm should be delayed

These settings must be done for each Field separately.

¹ State settings via the FIELD menu at “Channel can be disabled”, enable the function , choose the digital input you want to use and enter the “Disable Text” you want to appear when the specific Digital input is activated



² With the Toggle function a specified field can be used to switch a relay ON/OFF
The Relay symbol will appear in the specified Field (Open or Close)
By pressing the field the relay will be closed ↴ or opened ↴ (depending on the status)
[all other functions of the specified field are disabled if the Toggle function is active]

Field 1

Back



Low Settings

High Settings



Low Settings Field 1

Back

Low Settings

Warning

Value

0.0

Hysteresis

0.0

Enabled



Buzzer enabled



Digital output channel

0

Alarm

Value

0.0

Hysteresis

0.0

Enabled



Buzzer enabled



Digital output channel

0



Field 1

Back



Low Settings

High Settings



High Settings Field 1

Back

High Settings

Warning

Value

0.0

Hysteresis

0.0

Enabled



Buzzer enabled



Digital output channel

0

Alarm

Value

0.0

Hysteresis

0.0

Enabled



Buzzer enabled



Digital output channel

0



Low or High Alarm settings (Field 1 ...8)



Warning: the background colour will change from white/green to yellow

Value: enter the threshold value at which the warning should be enabled

Hysteresis: enter the value on which warning should be enabled/disabled

Enabled: select if the warning alarm should be ON ☒ or OFF ☐

Buzzer enabled: select if the buzzer should ON ☒ or OFF ☐ at a warning alarm

Digital output channel: select the digital output which should be enabled at a warning alarm (0 = NO digital output is selected)

Alarm: The background colour will change from white/green/yellow to red

Value: enter the threshold value at which the alarm should be enabled

Hysteresis: enter the value on which alarm should be enabled/disabled


Enabled: select if the alarm should be ON ☒ or OFF ☐

Buzzer enabled: select if the buzzer should ON ☒ or OFF ☐ at an alarm

Digital output channel: select the digital output which should be enabled at an alarm (0 = NO digital output is selected)




These Lo/High warning and alarms need be set for each field separately




Operating current

By operating current the alarm is OFF below the threshold and ON at reaching the threshold.



Quiescent current


By quiescent current the alarm is ON below the threshold and switched OFF on reaching the threshold.



Switching-on delay

The switching-ON delay is activated via an alarm and e.g. switched 10 seconds after reaching the switching threshold, a short-term exceedance of the switching value does not cause an alarm, respectively does not cause a switching operation of the relay. The switching-OFF delay operates in the same way, keeps the alarm / the relay switched longer for the parametrised time.


5.4 SAVE:



SAVE:

Click on “Save” to save settings

5.5 BACK:





BACK:

Click on “Back” to:


Return to measuring modus

Or


Confirm to save settings? → YES or NO
and return to measuring modus



6 OUT OF USE FUNCTION:




7 DAY – NIGHT FUNCTION:




8 DOWNLOAD THE LOGFILE VIA Wi-Fi



The saved data can be downloaded from the display via the WiFi option to your smartphone and opened as a .CSV file. The saved data also can be extracted from the SD-card, the SD-card has to be removed from the display and put into a computer. Files can be found in the "Logging" folder.
[Wi-Fi only active with the PRIObox]



If your smartphone Wi-fi network is set to **PEDAK (password Pedak1234)** and the QR-code is scanned you enter the **neverssl.com** website or enter the **neverssl.com** website manually via the browser.



Select the desired folder



Click on the .csv file you want to download to view the Logfile.

9 MODBUS:

Modbus TCP/IP (Switch – “Slave”)




The display can be used as Modbus only (“Slave”) device [Slave ID: 1 and Port ID: 502].

All settings must be done over the Modbus TCP/IP connection


[settings made in all other menu’s will be ignored]

The IP address to be used is shown in the display if confirmed to use “Switch Version”, this is the same IP address as shown under “Current IP” in the “Main settings” menu.


This IP address can be changed via “IP settings” in the “Main settings” menu **in standard modus only!**



If you change the IP-address you have **Save** (1) and **Restart** (2) the display, with the buttons at the bottom of the IP-settings menu. Else it will not be active !



It is not necessary to send the complete registers every time, only sending the changes will do. Sending the complete registers is only required when registers are missing (e.g. power outage)






The data is saved on the SD-card but cannot be extracted via Wi-Fi in the Modbus-Switch modus
[Data readout via Wi-Fi only with the PRIObbox]



If you want to switch back to the Standard Modus click on the Pedak logo and confirm you want to switch back.



Modbus TCP/IP (Server – “Master”)



The display can be used as Modbus (Server - Master) device.


Only the measured values only can be send to the display over Modbus TCP/IP connection, all other settings (like Alarms, Name, Delay, Hysteresis, etc.) must be done in the “Field” settings menu.

The rest of the Modbus settings can be made via “Sensor input” and “Modbus TCP Server”
[see chapter 5.2]

This modus also can be used to readout measured values from the display.

For this use the “Modbus TCP/IP – **read only**” channels (channel 9 ... 16)

The decimal point of the “read only” Integer registers can be set by using the “devisor”
[example: value 21,4 in the display → standard Integer is 21 → devisor = 10 → Integer = 214]



The data is saved on the SD-card but cannot be extracted via Wi-Fi in the Modbus-TCP/IP modus
[Data readout via Wi-Fi only with the PRIObbox]



The maximum of displays in a Modbus line is in theory 247 on a class A network and max. 100m cable length and using the correct peripheral equipment (router, etc.)

Modbus RS-485 (Client – “Master”)



The display can be used as Modbus (Client - Master) device.

Only the measured values can be send to the display over Modbus RS-485 connection, all other settings (like Alarms, Name, Delay, Hysteresis, etc.) must be done in the “Field” settings menu.

The rest of the Modbus settings can be made via “Sensor input” and “Modbus RS485 Client ”
[see chapter 5.2]



The data is saved on the SD-card but cannot be extracted via Wi-Fi in the Modbus-RS485 modus
[Data readout via Wi-Fi only with the PRIIObox]



Max. 32 displays in one Modbus line, depending on the quality (electrical load) of the network.



Only measured values can be send to the display, but **NOT** read from the display in the “Modbus RS485 – client” modus.

Modbus Registers – for “Master” modus

Register start	Register end	Datatype	Value	Notes
1		Integer (16 bits, Little Endian)	Modbus 1, analog value channel 1	TCP write / RS485 write
2		Integer (16 bits, Little Endian)	Modbus 2, analog value channel 2	TCP write / RS485 write
3		Integer (16 bits, Little Endian)	Modbus 3, analog value channel 3	TCP write / RS485 write
4		Integer (16 bits, Little Endian)	Modbus 4, analog value channel 4	TCP write / RS485 write
5		Integer (16 bits, Little Endian)	Modbus 5, analog value channel 5	TCP write / RS485 write
6		Integer (16 bits, Little Endian)	Modbus 6, analog value channel 6	TCP write / RS485 write
7		Integer (16 bits, Little Endian)	Modbus 7, analog value channel 7	TCP write / RS485 write
8		Integer (16 bits, Little Endian)	Modbus 8, analog value channel 8	TCP write / RS485 write
9		Integer (16 bits, Little Endian)	Modbus 9, analog value channel 1	TCP Read only, channel 1
10		Integer (16 bits, Little Endian)	Modbus 10, analog value channel 2	TCP Read only, channel 2
11		Integer (16 bits, Little Endian)	Modbus 11, analog value channel 3	TCP Read only, channel 3
12		Integer (16 bits, Little Endian)	Modbus 12, analog value channel 4	TCP Read only, channel 4
13		Integer (16 bits, Little Endian)	Modbus 13, analog value channel 5	TCP Read only, channel 5
14		Integer (16 bits, Little Endian)	Modbus 14, analog value channel 6	TCP Read only, channel 6
15		Integer (16 bits, Little Endian)	Modbus 15, analog value channel 7	TCP Read only, channel 7
16		Integer (16 bits, Little Endian)	Modbus 16, analog value channel 8	TCP Read only, channel 8



If you use the TCP/IP connection (channel 9...16) to readout measured values, use the “devisor” under the TCP/IP settings to get decimal numbers

e.g.: measured value 25,8 → devisor “1” → readout 25 → devisor “10” → readout 258


Modbus Registers – for “Slave” modus

Register start	Register end	Datatype	Value	Notes
1	2	Float (32 bits, Little Endian)	Modbus 1, analog value channel 1	
3	4	Float (32 bits, Little Endian)	Modbus 2, analog value channel 2	
5	6	Float (32 bits, Little Endian)	Modbus 3, analog value channel 3	
7	8	Float (32 bits, Little Endian)	Modbus 4, analog value channel 4	
9	10	Float (32 bits, Little Endian)	Modbus 5, analog value channel 5	
11	12	Float (32 bits, Little Endian)	Modbus 6, analog value channel 6	
13	14	Float (32 bits, Little Endian)	Modbus 7, analog value channel 7	
15	16	Float (32 bits, Little Endian)	Modbus 8, analog value channel 8	
31		Bitpattern 16 bits	Modbus 1, alarm status	Bit 0: Warning status; Bit 1: Alarm status; Bit 2: Buzzer on; Bit 3: Buzzer muted; Note: Buzzer will only sound if warning of alarm is active
32		Bitpattern 16 bits	Modbus 2, alarm status	Bit 0: Warning status; Bit 1: Alarm status; Bit 2: Buzzer on; Bit 3: Buzzer muted; Note: Buzzer will only sound if warning of alarm is active
33		Bitpattern 16 bits	Modbus 3, alarm status	Bit 0: Warning status; Bit 1: Alarm status; Bit 2: Buzzer on; Bit 3: Buzzer muted; Note: Buzzer will only sound if warning of alarm is active
34		Bitpattern 16 bits	Modbus 4, alarm status	Bit 0: Warning status; Bit 1: Alarm status; Bit 2: Buzzer on; Bit 3: Buzzer muted; Note: Buzzer will only sound if warning of alarm is active
35		Bitpattern 16 bits	Modbus 5, alarm status	Bit 0: Warning status; Bit 1: Alarm status; Bit 2: Buzzer on; Bit 3: Buzzer muted; Note: Buzzer will only sound if warning of alarm is active
36		Bitpattern 16 bits	Modbus 6, alarm status	Bit 0: Warning status; Bit 1: Alarm status; Bit 2: Buzzer on; Bit 3: Buzzer muted; Note: Buzzer will only sound if warning of alarm is active
37		Bitpattern 16 bits	Modbus 7, alarm status	Bit 0: Warning status; Bit 1: Alarm status; Bit 2: Buzzer on; Bit 3: Buzzer muted; Note: Buzzer will only sound if warning of alarm is active
38		Bitpattern 16 bits	Modbus 8, alarm status	Bit 0: Warning status; Bit 1: Alarm status; Bit 2: Buzzer on; Bit 3: Buzzer muted; Note: Buzzer will only sound if warning of alarm is active
41		Integer (16 bits, Little Endian)	Channel 1, number of decimals	In case the value is set higher than 10, a value of 10 is used instead
42		Integer (16 bits, Little Endian)	Channel 2, number of decimals	In case the value is set higher than 10, a value of 10 is used instead
43		Integer (16 bits, Little Endian)	Channel 3, number of decimals	In case the value is set higher than 10, a value of 10 is used instead
44		Integer (16 bits, Little Endian)	Channel 4, number of decimals	In case the value is set higher than 10, a value of 10 is used instead
45		Integer (16 bits, Little Endian)	Channel 5, number of decimals	In case the value is set higher than 10, a value of 10 is used instead
46		Integer (16 bits, Little Endian)	Channel 6, number of decimals	In case the value is set higher than 10, a value of 10 is used instead
47		Integer (16 bits, Little Endian)	Channel 7, number of decimals	In case the value is set higher than 10, a value of 10 is used instead
48		Integer (16 bits, Little Endian)	Channel 8, number of decimals	In case the value is set higher than 10, a value of 10 is used instead
101	115	Char (2x 8 bits ascii, Little Endian)	Channel 1, panel name	Last byte will be set to NULL
116	130	Char (2x 8 bits ascii, Little Endian)	Channel 1, Unit	Last byte will be set to NULL
131	145	Char (2x 8 bits ascii, Little Endian)	Channel 1, room name	Last byte will be set to NULL
146	160	Char (2x 8 bits ascii, Little Endian)	Channel 2, panel name	Last byte will be set to NULL
161	175	Char (2x 8 bits ascii, Little Endian)	Channel 2, Unit	Last byte will be set to NULL
176	190	Char (2x 8 bits ascii, Little Endian)	Channel 2, room name	Last byte will be set to NULL
191	205	Char (2x 8 bits ascii, Little Endian)	Channel 3, panel name	Last byte will be set to NULL
206	220	Char (2x 8 bits ascii, Little Endian)	Channel 3, Unit	Last byte will be set to NULL
221	235	Char (2x 8 bits ascii, Little Endian)	Channel 3, room name	Last byte will be set to NULL
236	250	Char (2x 8 bits ascii, Little Endian)	Channel 4, panel name	Last byte will be set to NULL
251	265	Char (2x 8 bits ascii, Little Endian)	Channel 4, Unit	Last byte will be set to NULL
266	280	Char (2x 8 bits ascii, Little Endian)	Channel 4, room name	Last byte will be set to NULL
281	295	Char (2x 8 bits ascii, Little Endian)	Channel 5, panel name	Last byte will be set to NULL
296	310	Char (2x 8 bits ascii, Little Endian)	Channel 5, Unit	Last byte will be set to NULL
311	325	Char (2x 8 bits ascii, Little Endian)	Channel 5, room name	Last byte will be set to NULL
326	340	Char (2x 8 bits ascii, Little Endian)	Channel 6, panel name	Last byte will be set to NULL

341	355	Char (2x 8 bits ascii, Little Endian)	Channel 6, Unit	Last byte will be set to NULL
356	370	Char (2x 8 bits ascii, Little Endian)	Channel 6, room name	Last byte will be set to NULL
371	385	Char (2x 8 bits ascii, Little Endian)	Channel 7, panel name	Last byte will be set to NULL
386	400	Char (2x 8 bits ascii, Little Endian)	Channel 7, Unit	Last byte will be set to NULL
401	415	Char (2x 8 bits ascii, Little Endian)	Channel 7, room name	Last byte will be set to NULL
416	430	Char (2x 8 bits ascii, Little Endian)	Channel 8, panel name	Last byte will be set to NULL
431	445	Char (2x 8 bits ascii, Little Endian)	Channel 8, Unit	Last byte will be set to NULL
446	460	Char (2x 8 bits ascii, Little Endian)	Channel 8, room name	Last byte will be set to NULL
501		Integer (16 bits, Little Endian)	Active channel count	Valid values are 1..8
502		Integer (16 bits, Little Endian)	Screen orientation	0 = Horizontal, 1 = Vertical
503		Integer (16 bits, Little Endian)	Screen brightness day	Valid values are 0..100
504		Integer (16 bits, Little Endian)	Screen brightness night	Valid values are 0..100
551		Bitpattern 16 bits	Channel 1, Settings	Bit 0: Green enabled; Bit 1: Manual scaling enabled
552		Bitpattern 16 bits	Channel 2, Settings	Bit 0: Green enabled; Bit 1: Manual scaling enabled
553		Bitpattern 16 bits	Channel 3, Settings	Bit 0: Green enabled; Bit 1: Manual scaling enabled
554		Bitpattern 16 bits	Channel 4, Settings	Bit 0: Green enabled; Bit 1: Manual scaling enabled
555		Bitpattern 16 bits	Channel 5, Settings	Bit 0: Green enabled; Bit 1: Manual scaling enabled
556		Bitpattern 16 bits	Channel 6, Settings	Bit 0: Green enabled; Bit 1: Manual scaling enabled
557		Bitpattern 16 bits	Channel 7, Settings	Bit 0: Green enabled; Bit 1: Manual scaling enabled
558		Bitpattern 16 bits	Channel 8, Settings	Bit 0: Green enabled; Bit 1: Manual scaling enabled
559		2 bytes	Channel 1, Font size	Byte 0: Font size value; Byte 1: Font size tekst; Valid values are 16, 26, 30, 48, 55
560		2 bytes	Channel 2, Font size	Byte 0: Font size value; Byte 1: Font size tekst; Valid values are 16, 26, 30, 48, 55
561		2 bytes	Channel 3, Font size	Byte 0: Font size value; Byte 1: Font size tekst; Valid values are 16, 26, 30, 48, 55
562		2 bytes	Channel 4, Font size	Byte 0: Font size value; Byte 1: Font size tekst; Valid values are 16, 26, 30, 48, 55
563		2 bytes	Channel 5, Font size	Byte 0: Font size value; Byte 1: Font size tekst; Valid values are 16, 26, 30, 48, 55
564		2 bytes	Channel 6, Font size	Byte 0: Font size value; Byte 1: Font size tekst; Valid values are 16, 26, 30, 48, 55
565		2 bytes	Channel 7, Font size	Byte 0: Font size value; Byte 1: Font size tekst; Valid values are 16, 26, 30, 48, 55
566		2 bytes	Channel 8, Font size	Byte 0: Font size value; Byte 1: Font size tekst; Valid values are 16, 26, 30, 48, 55
571	572	Float (32 bits, Little Endian)	Channel 1, Graph mimimum	Bit 1 for this channel settings has to be set, in order to be used
573	574	Float (32 bits, Little Endian)	Channel 1, Graph maximum	Bit 1 for this channel settings has to be set, in order to be used
575	576	Float (32 bits, Little Endian)	Channel 2, Graph mimimum	Bit 1 for this channel settings has to be set, in order to be used
577	578	Float (32 bits, Little Endian)	Channel 2, Graph maximum	Bit 1 for this channel settings has to be set, in order to be used
579	580	Float (32 bits, Little Endian)	Channel 3, Graph mimimum	Bit 1 for this channel settings has to be set, in order to be used
581	582	Float (32 bits, Little Endian)	Channel 3, Graph maximum	Bit 1 for this channel settings has to be set, in order to be used
583	584	Float (32 bits, Little Endian)	Channel 4, Graph mimimum	Bit 1 for this channel settings has to be set, in order to be used
585	586	Float (32 bits, Little Endian)	Channel 4, Graph maximum	Bit 1 for this channel settings has to be set, in order to be used
587	588	Float (32 bits, Little Endian)	Channel 5, Graph mimimum	Bit 1 for this channel settings has to be set, in order to be used
589	590	Float (32 bits, Little Endian)	Channel 5, Graph maximum	Bit 1 for this channel settings has to be set, in order to be used
591	592	Float (32 bits, Little Endian)	Channel 6, Graph mimimum	Bit 1 for this channel settings has to be set, in order to be used
593	594	Float (32 bits, Little Endian)	Channel 6, Graph maximum	Bit 1 for this channel settings has to be set, in order to be used
595	596	Float (32 bits, Little Endian)	Channel 7, Graph mimimum	Bit 1 for this channel settings has to be set, in order to be used
597	598	Float (32 bits, Little Endian)	Channel 7, Graph maximum	Bit 1 for this channel settings has to be set, in order to be used
599	600	Float (32 bits, Little Endian)	Channel 8, Graph mimimum	Bit 1 for this channel settings has to be set, in order to be used
601	602	Float (32 bits, Little Endian)	Channel 8, Graph maximum	Bit 1 for this channel settings has to be set, in order to be used
611	612	Float (32 bits, Little Endian)	Channel 1, Graph low alarm line	Note that this is only for the graph. The alarm status still has to be set. Write NaN to disable the line
613	614	Float (32 bits, Little Endian)	Channel 1, Graph low warning line	Note that this is only for the graph. The alarm status still has to be set. Write NaN to disable the line
615	616	Float (32 bits, Little Endian)	Channel 1, Graph high warning line	Note that this is only for the graph. The alarm status still has to be set. Write NaN to disable the line

RS-485 Connection


The RS-485 interface has to be connected via shielded data line with twisted pair wires. Each end of the bus segment needs to be connected to an termination of the bus wire. It is required to ensure a secure data transfer to the bus. Therefore a resistance (120Ω) must be switched between the line Data A- and Data (+).



10 DEFAULT FACTORY SETTINGS:

Main Settings				
Language	English			
Screen layout	Horizontal <i>[landscape]</i>			
Visible screens	4			
Brightness Day (%)	100			
Brightness night (%)	10			
Auto Night Delay (min.)	0 <i>[Off]</i>			
Pincode	Disabled			
Access Point SSID	Pedak			
Access Point Password	Pedak1234			
Access Point	enabled			
Buzzer Frequency	Normal			
Panel Settings	Panel 1:	Panel 2:	Panel 3:	Panel 4:
Name	"Temperature"	"Humidity"	"Pressure"	"Pressure"
Room name	"Room 1"	"Room 1"	"Room 1"	"Room 2"
Unit	"°C"	"%"	"Pa"	"Pa"
Text font size	30	30	30	30
Value font size	48	48	48	48
Channel	Analog 1	Analog 2	Analog 3	Analog 4
Background colour	White	White	White	White
Number of decimals	1	1	1	1
File Logging Enabled	On	On	On	On
Toggle panel	Off	Off	Off	Off
Relay index	0 <i>[no relay]</i>	0 <i>[no relay]</i>	0 <i>[no relay]</i>	0 <i>[no relay]</i>
Channel Disable Enabled	Off <i>[disabled]</i>	Off <i>[disabled]</i>	Off <i>[disabled]</i>	Off <i>[disabled]</i>
Disable Channel Name	Off	Off	Off	Off
Disable Text	<i>[empty]</i>	<i>[empty]</i>	<i>[empty]</i>	<i>[empty]</i>
Alarm Channel Enabled	Off	Off	Off	Off
Alarm Channel Delay	0 <i>[no delay]</i>	0 <i>[no delay]</i>	0 <i>[no delay]</i>	0 <i>[no delay]</i>
Acquisition	<i>[Analog 1]</i>	<i>[Analog 2]</i>	<i>[Analog 3]</i>	<i>[Analog 4]</i>
Input	4...20mA	4...20mA	4...20mA	4...20mA
Input Range	0...100	0...100	0...100	0...100
Smoothing	98.06	98.06	98.06	98.06
Graphical data				
Manual Scaling Enabled	On	On	On	On
Minimum	0	0	0	0
Maximum	100	100	100	100
Modbus RS485 Client				
Baud Rate	115200			
Data Bits	8			
Parity	None			
Stop bits	1			
Address	1			

11 Menu Layout:



12 SCREEN LAYOUT:

Horizontal

The horizontal screen layout examples show the following field arrangements:

- Example 1: A single large field labeled "Field 1".
- Example 2: Two fields stacked vertically, labeled "Field 1" and "Field 2".
- Example 3: One field labeled "Field 1" at the top, and two fields labeled "Field 2" and "Field 3" side-by-side at the bottom.
- Example 4: A 2x2 grid of four fields labeled "Field 1", "Field 2", "Field 3", and "Field 4".
- Example 5: A 2x3 grid of six fields labeled "Field 1" through "Field 6".
- Example 6: A 2x4 grid of eight fields labeled "Field 1" through "Field 8".

Vertical

The vertical screen layout examples show the following field arrangements:

- Example 1: Two fields stacked vertically, labeled "Field 1" and "Field 2".
- Example 2: Three fields stacked vertically, labeled "Field 1", "Field 2", and "Field 3".
- Example 3: Four fields stacked vertically, labeled "Field 1", "Field 2", "Field 3", and "Field 4".
- Example 4: A 2x2 grid of four fields labeled "Field 1", "Field 2", "Field 3", and "Field 4".
- Example 5: A 3x2 grid of six fields labeled "Field 1" through "Field 6".
- Example 6: A 4x2 grid of eight fields labeled "Field 1" through "Field 8".

13 TROUBLE SHOOTINGS:

Display Message	Problem	Solution
(No message)	Display and/or PRIO-box does not turn ON	Check if the power supply is connected and check the polarity
Error 1	“Channel unknown” A channel has been set that not or no longer exists. Or the channel name has been changed but not in the readout (“Field” menu)	Check channel and/or channel settings
Error 2	“Probe error” nLink/nSens/Modbus client	Check the nLink/nSens sensor or the Modbus-485 signal
Error 3	“Connection lost” Time out for Modbus-485 or nLink/nSens	Check communication signal or connection cable
Error 4	“Signal not updated” No new data has been received since the screen is loaded. This message should disappear automatically.	Update the Modbus signal or check the Modbus connection
Error 5	“Other error” Under normal circumstances, this should never appear. If it does appear, a factory reset is recommended because something is wrong with the configuration.	Check the configuration. If the problem does not disappear please send a copy of the settings to your dealer for analyses.
File too short	Software failure	Display needs to be returned to Pedak
User code exit	Wrong SD-card	Install the supplied SD-card
Storage error: Media error	No SD-card is installed	Install the supplied SD-card
(no message)	Modbus failure	No 120Ω resistor is used
(no message)	Modbus failure	To many displays in one Modbus line. @RS-485 this is approx. 32 displays depending on the quality (electrical load) of the network. @TCP/IP it is in theory “247” on a class A network and max. 100m cable length and using the correct peripheral equipment (router, etc.)
(no message)	Modbus failure	Check Modbus settings

13 EXPANSION MODULES:

The PRIObbox has standard 4 analogue inputs, 4 nSens inputs, 2 digital inputs and 2 relays but this can be expanded with 8 extra analogue and/or digital inputs [NOTE: only 8 channels can be displayed at once] and/or 4 relays¹.


The analogue expansion module can be connected to the P5/P7 display directly (via the CAN-bus connection) but the relay and/or digital I/O expansion modules need to be connected to the PRIObbox (via Flat-cable).

In the analogue expansion module you choose the input cards you prefer (0-5V / 0-10V / 0-20mA)



Ask your dealer for the possibilities.

The relay module has 4 relays¹ [230VAC – 10A / 24VDC – 10A]



14 ORDERING CODES:

Item:	Order code:	Description:
P5 Display	PEDAKP5	5" Display incl. wall box
P7 Display	PEDAKP7	7" Display incl. wall box
PRIObbox	PRIOBOX	Input / output box for Pedak-P5 or P7
Wall box P5	WALLBOXP5	Spare wall box for Pedak-P5 display (5")
Wall box P7	WALLBOXP7	Spare wall box for Pedak-P7 display (7")
Puzzle-Master-IO	PUMASIO	Puzzle Master IO module (excl. analogue input cards)
0-10V Input card	PU10VINP	0-10V analogue input card (for Puzzle-Master-IO)
0-5V Input card	PU05VINP	0-5V analogue input card (for Puzzle-Master-IO)
0-20mA Input card	PU20MAINP	0-20mA analogue input card (for Puzzle-Master-IO)
Relay Module ¹	PURELAY	4x Relay (230VAC – 10A / 24VDC – 10A) [Priobox needed]
Slave I/O Module	PUSLAVE	8x digital input and 8x digital output [Priobox needed]

¹ under development



Pedak meettechniek
Roorveld 1
6093 PL Heythuysen (NL)
T +31 (0)475 49 74 24
E info@pedak.nl



www.pedak.nl