



Description

-Humidity/-temperature sensors in these series are

used to measure relative humidity or temperature or relative humidity and temperature in air and other non-aggressive gases in explosion hazardous arears and in locations with inflammable dust.

The sensors comprise a sensor part with a sintered filter mounted on a robust aluminium die-cast housing (transmitter part), both made of stainless steel.

Connection to a non-intrinsically safe electric circuit for humidity (F*C3.Ex/8) and for temperature sensors (T*C3. Ex/8) is achieved with a 1-channel transmitter power supply unit and for the combined humidity and temperature sensors(K*C3.Ex/8) either with a 2-channel or with two 1-channel transmitter power supply units with galvanic isolation between input-/output circuits and power supply.

Model variants - product reference

Measured variable	GC series	KC series
F (relative humidity)	FGC3.Ex/8	FKC3.Ex/8
K (rel. humidity / temp.)	KGC3.Ex/8	KKC3.Ex/8
T (temperature)	TGC3.Ex/8	TKC3.Ex/8
weight approx.	380 g	470 g
⟨ξ⊷⟩ II 1/2 G Ex ia I	IC: T4	



II 2D Ex tb IIIC T95°C

-40°C ≤ T₂ ≤ +80°C

Approved for use in explosion hazardous areas :

EC Design Test Certificate IBExU 07 ATEX 1114

The sensor **KKC3.Ex/8-K33** corresponds to the sensor **KKC3.Ex/8**, however with the following differences:

appropriate to use in ethylene oxide athmosphere and at pressure up to pabs = 50mbar

The admission to use the sensor for gas sterilisation by ethylene oxide with low-pressure up to pabs = 50 mbar according to Certificate of Clearance no. IB-07-3-252 to EC-Type Examination Certificate IBExU 07 ATEX 1114 The Certificate of Clearance no. IB-07-3-252 apply for following application conditions:

ambient pressure @ 45 - 55 °C air 50 mbar abs.@ 45 - 55 °C air with 20 % O2 50 mbar abs.@ 45 -55 °C air and 100 % rH 120 - 850 mbar abs.@ 45 - 55 °C with 0 - 8 % O2 and 0 - 65 % ethylene oxide and 20 - 100 % rH

Product info sheet no. C 4.8

Humidity/-temperature sensorsWith "ATEX" licence for locations with explosive gas atmosphere and for locations with inflammable dust for use in atmospheric conditions

Technical data

Outnut	1.	rolativo	humidity

Output range 1:	0100%rh
Output signal 1:	420 mA
Accuracy (MR 595%rh at 1040 °C)	±2%rh
at T<10 °C; T>40°C	0.1%/K additional

Output 2: temperature

Carpar =: tomporatar c	
Measuring element (ref. DIN IEC 751)	Pt 100 class B
Output range 1:	+80 °C
(special models with special measuring rang	ge on demand)
Output signal 2:	420 mA
Accuracy at 23°C	±0.2 K
other range	±0.3 K
at T<10°C, T>40°C	±0.007 K/K additonal

Others

Storage temperature		40+80°C
Approved operating temper	rature range	40+80°C
Maximum surface temperat	ture of housing	95°C
Sensor operating voltage	1324V DC	(intrinsically safe)

Maximum admissible input voltage U,	24V DC
Maximum admissible input amperage I,	100 mA
Maximum admissible input power P,	780 mW
Maximum inner capacity C,	negligible
Maximum inner inductivity L,	negligible
Degree of protection	IP 66
electrical equipment in instrument group II wit	h protection provided
	by housing

Housing material
Sensor part stainless stee
Transmitter part alu-diecas
Cable screwing M16 x 1.5
clamping range 37 mm
initial torque
(for recommended cable type) 4.0 Nm

Cable between sensor and transmitter power supply unit, shielde	d
Recommended type NF14 (Metrofur	ık)
Maximum power transmission length	m
Maximum cable capacity 20nF/100	m
Ends of the power line Wire sleeves w	ith
plastic colla	ars

Recommended transmitter power supply units by Hans Turck GmbH & Co. KG

IM33-11Ex-Hi/24V DC (1-channel)

IM33-22Ex-Hi/24V DC (2-channel)

All data and certificates at www.turck.com

Conformity with European Standards

spiosion protection guideline 2014/34/EU	
General requirements	EN 60079-0:2012
Intrinsic safety "i"	EN 60079-11:2012
Category 1 G electrical apparatus	EN 60079-26:2007
Dust protection by enclosures "t"	EN 60079-31:2009

Directive about electromagnetic compatibility 2014/30/EU

General requiremen	nts	EN 6132	6-1:2013
Special requirement	ts	EN 61326-	2-3:2013

This information is based on current knowledge and is intended to provide details of our products and their possible applications. It does not, therefore, act as a guarantee of specific properties of the products described or of their suitability for a particular application. It is our experience that the equipment may be used across a broad spectrum of applications under the most varied conditions and loads. We cannot appraise every individual case. Purchasers and/or users are responsible for checking the equipment for suitability for any particular application. Any existing industrial rights of protection must be observed. The perfect quality of our products is guaranteed under our General Conditions of Sale. Issue valid: from June 2016 C48_E. Subject to modifications, current version available at www.pedak.nl This issue supersedes all previous technical leaflets.

-humidity/temperature sensors should be installed in a location which is representative for measuring the environmental conditions.

Connection to a non-intrinsically safe power circuit is achieved by using either one or two transmitter power supply units $(\textbf{U}_0, \textbf{I}_0, \textbf{P}_0)$ according to the connection diagram. To verify the intrinsic safety in a simple, intrinsically safe electric circuit, the values of the intrinsically safe equipment $(\textbf{U}_i, \textbf{I}_i, \textbf{P}_i, \textbf{C}_i \text{ and } \textbf{L}_i)$, of the corresponding electrical equipment (transmitter power supply $\textbf{U}_0, \textbf{I}_0, \textbf{P}_0, \textbf{C}_0 \text{ and } \textbf{L}_0)$ and of the cable (C und L) need to be compared to ensure that the intrinsically safe equipment is not overloaded and the energy stores L and C are not greater than \textbf{L}_0 and \textbf{C}_0 of the corresponding equipment. For the performance, even with a trapezoidal characteristic curve, the value \textbf{P}_0 of the transmitter power supply is to be used.

Basically, the max. cable length only depends on $\mathrm{C}_{\scriptscriptstyle 0}$ of the transmitter power supply and on the type of cable used, as circuit engineering measures have been taken to ensure that the internal capacity of the sensor does not impact externally. We recommend the cable type NF14 and a max. cable length of 200m.

During installation, the additional requirements for the

protection type "i" -intrinsically safe according to DIN EN 60079-14, - must be complied with. Only fixed cables and electric lines may be inserted into the cable gland. After connecting it up, the housing must be sealed tightly again. To do so, the screws in the cover must be tightened with a torque of 1.5 to 2.0 NM.


The intrinsicaly safe humidity and temperature sensors (type of protection "ia") can also be used as class 1 equipment. If you do this, make sure you only use assembly kit **ZA40** when attaching the sensor to a partition barrier.

Please order assembly kit **ZA40** separately!


Please refer to pages 3 and 4 for further safety advice and dimension diagrams for connecting to zone 0.

The sensor can be installed in any position. However, do avoid positions where water ingress can occur. Dew formation and splashes do not damage the sensor, although corrupted measurement readings are recorded until all the moisture on and directly around the sensor element has dried up.

In order to maintain immunity from interference while using the sensor, you are required to connect up the sensor with a screened cable which has been fitted into the sensor's EMC cable gland by a qualified electrician.



Connection diagrams



Installing a humidity and temperature sensor with connection to zone 0

The **-humidity/temperature sensor** is to be mounted in the wall of the hazardous area with class 1 requirements by using assembly kit ZA 40 and according to the dimension diagram showing connections to zone 0 on page 4, .

This partition barrier must be made of corrosion-resistant material compatible with the application, must be homogenous and have a wall thickness of at least 3 mm, and must have a thread of M25x1,5.

Otherwise additional protection measures are necessary in accordance with DIN EN 60079-26 .

When the sensor is removed there is a danger of releasing potentially explosive atmosphere and flames penetrating from the outside. For this reason the opening must be closed again immediately.

Only attach the humidity and temperature sensors using the increased safety-type cable gland provided in the assembly kit **ZA 40**.

Please order assembly kit ZA 40 separately.

The screw connections are to be tightened using a tool with a tightening torque of 10 Nm.

When removing the sensor, the increased safety-type cable gland stays in the partition barrier. The opening is closed again by simply replacing the normal seal insert with the increased safety-type filler seal insert from the assembly kit **ZA 40**.

Special models

On request **-humidity/temperature sensors** with "Ex" certification can also be supplied with the following options:

Connecting cable Ø 610 mm	all model versions
stainless steel/teflon filter ZE28 for extreme applications	all model versions
290 mm long sensor tube	series KC
Special measurement ranges with Temperature (0 50°C, 0 100°C and -3070°C)	model versions K*C3.Ex/8 and T*C3.Ex/8

Maintenance and Cleaning

If used as intended and if the assembly instructions and ambient conditions have been taken into consideration, then no running maintenance is necessary.

In order to arrange a simple test of the functionality of the sensor on the site, we recommend the **-humidity**

standard type ZE 31/1 with the additional adapter type ZE 33 (product information no. F 5.2).

Dust does not damage the sensor but it negatively affects its dynamic behaviour.

The sintered filter can be carefully unscrewed and washed out if too much dust accumulates.

Loose dirt can also be removed from the measuring element by blowing or carefully flushing with distilled water. The sintered filter should be in an absolutely dry condition when it is screwed on again in order to avoid measurement errors. It is important not to touch the highly sensitive sensor element in the process. The screw connection on the sintered filter has to be firmly tightened.

Please refer to the *application instructions* for the sensing elements (product info sheet no. A 1) or check with the manufacturer for further information that you need to be aware of when using humidity sensors with capacitive sensing elements.

Caution!

Do not open sensors in a location with explosive dust atmosphere!

Repair

humidity and temperature sensors with "ATEX" certification may only ever be repaired by the manufacturer. The manufacturer will only use type-tested components as replacement parts.


While observing the following safety advice, the customer is only allowed to recalibrate the sensors.


Safety Information


The sensor may only be opened and operated while open when it is not in the potentially explosive atmosphere.

After calibration, the housing must be sealed tightly again. To do so, the screws in the cover must be tightened with a torque of 1.5 to 2.0 NM.


Potentiometer Configuration








Dimension diagrams for connection to zone 0



Assembly kit ZA 40

for connection to zone 0 (please order separately)



"increased safety" type cable gland

for sensor mounting in partition barrier



seal insert, closed to close the opening in the partition barrier after removing the sensor



Electrical connections must only be carried out by properly qualified personnel.

Attention must be paid to requirements for category -1G electrical apparatus according to DIN EN 60079-26 and also to installation advice.

When the sensor is removed there is a danger of releasing potentially explosive gas mixtures and flames penetrating from the outside.